# Fuse accessory selection guide

| Fuse family | Size | PCB Fuse clip | PCB Mount holder | Panel mount holder | In-line fuse holder | Fuse block |
|---|---|---|---|---|---|---|
| ABC<br>AGC | 1/4" x 1 1/4" | 1Axxxx | HBH-I<br>HBV-I | HTB<br>HK<br>HKP<br>HMR<br>HGA<br>HTJ | HRK<br>HHB<br>HFA<br>HHK<br>HHN<br>HFB<br>HHJ | S-4000<br>S-8000 |
| AGA | 1/4" x 5/8" | 1Axxxx | - | - | - | - |
| AGW | 1/4" x 7/8" | 1Axxxx | - | - | HRK<br>HHB | - |
| AGX | 1/4" x 1" | 1Axxxx | - | HJL | HRK<br>HHB<br>HHI | 3828-1 |
| AHC(A) | 1/4" x 1 1/4" | 1Axxxx | HBH-I<br>HBV-I | HVP | HVI | S-8000 |
| ATC | Auto Blade Fuse | 1A5600<br>1A5780 | - | - | HHF-JFCU | - |
| ATM | Auto Blade Fuse | 1A5778<br>1A5779 | - | - | HHM | - |
| C519 | 5 mm x 15 mm | 1Axxxx | - | - | HHT | - |
| C520 | 5 mm x 15 mm | 1Axxxx | - | - | HHT | - |
| FNM<br>FNQ | 13/32" x 1 1/2" | 1A3400 | - | HP | HEB | BMM603 |
| FNQ-R<br>KTK-R<br>LP-CC | 13/32" x 1 1/2" | 1A3400 | - | HP | - | BCM603 |
| FWH/5 | 1/4" x 1 1/4" | 1Axxxx | HBH-I<br>HBV-I | HVP | HVI | S-8000 |
| GBA<br>GLD | 1/4" x 1 1/4" | 1Axxxx | - | HLD | - | S-4000<br>S-8000 |
| GBB | 1/4" x 1 1/4" | 1Axxxx | HBH-I<br>HBV-I | HTB<br>HK<br>HKP<br>HMR<br>HGA<br>HTJ | HRK<br>HHB<br>HFA<br>HHK<br>HHN<br>HFB<br>HHJ | S-4000<br>S-8000 |
| GDA<br>GDB<br>GDC | 5 mm x 20 mm | 1Axxxx<br>HTC-2xxM | H15<br>HBH-M<br>HBV-M | HTB<br>HTC | HHT | HTC-15M<br>HTC-5x8M<br>HTC-78M |
| GMA | 5 mm x 20 mm | 1Axxxx<br>HTC-2xxM | H15<br>HBH-M<br>HBV-M | HTB<br>HTC | HHT | HTC-15M<br>HTC-5x8M<br>HTC-78M |
| GMC | 5 mm x 20 mm | 1Axxxx<br>HTC-2xxM | H15<br>HBH-M<br>HBV-M | HTB<br>HTC | HHT | HTC-15M<br>HTC-5x8M<br>HTC-78M |

# Fuse accessory selection guide



| | Fuse Family | Size | PCB Fuse Clip | PCB Mount Holder | Panel Mount Holder | In-Line Fuse Holder | Fuse Block |
|---|---|---|---|---|---|---|---|
| | GMD | 5 mm x 20 mm | 1Axxxx<br>HTC-2xxM | H15<br>HBH-M<br>HBV-M | HTB<br>HTC | HHT | HTC-15M<br>HTC-5x8M<br>HTC-78M |
| | KLM<br>KTK | 13/32" x 1 1/2" | 1A3400 | - | HP | HEB | BMM603 |
| | MDA<br>MDL<br>MDQ | 1/4" x 1 1/4" | 1Axxxx | HBH-I<br>HBV-I | HTB<br>HK<br>HKP<br>HMR<br>HGA<br>HTC | HRK<br>HHB<br>HFA<br>HHK<br>HHN<br>HFB<br>HHJ | S-4000<br>S-8000 |
| | MDH | 1/4" x 1 1/4" | 1Axxxx | HBH-I<br>HBV-I | HTB<br>HK<br>HKP<br>HMR<br>HGA<br>HTC | HRK<br>HHB<br>HVI<br>HHK<br>HHN<br>HFB<br>HHJ | S-4000<br>S-8000 |
| | PCTron | - | - | BK-PCS | - | - | - |
| | S500<br>S501 | 5 mm x 20 mm | 1Axxxx<br>HTC-2xxM | H15<br>HBH-M<br>HBV-M | HTB | HHT | HTC-15M<br>HTC-60M<br>HTC-78M |
| | S505<br>S506 | 5 mm x 20 mm | 1Axxxx<br>HTC-2xxM | H15<br>HBH-M<br>HBV-M | HTB | HHT | HTC-15M<br>HTC-60M<br>HTC-78M |
| | SC-1 to 15A | 13/32" x 1.31" | 1A3400 | - | HPS-EE | HEG | BG3011PQ |
| | SC-20A | 13/32" x 1.41" | 1A3400 | - | HPS-JJ | HEH | BG3011PQ |
| | SC-25 to 30A | 13/32" x 1.62" | 1A3400 | - | HPS-FF | HEC | BG3011PQ |
| | SC-35 to 60A | 13/32" x 2 1/4" | 1A3400 | - | - | HEJ | G30060-1CR |
| | SFE | 1/4" x various lengths<br>(5/8" to 1 7/16") | 1Axxxx | - | - | HR/HM | - |
| | SR-5 / SR-5F / SR-5H<br>SS-5 / SS-5F / SR-5H | - | - | BK-PCS | - | - | - |
| | TDC10/11 | 1/4" x 1 1/4" | 1Axxxx | HBH-I<br>HBV-I | HTB<br>HK<br>HKP<br>HMR<br>HGA-C | HRK<br>HHB<br>HFA<br>HHK<br>HHN<br>HFB<br>HHJ | S-8000 |
| | TDC180<br>TDC600 | 1/4" x 1" | 1Axxxx | - | HJL<br>HJM | HRK<br>HHB<br>HHI | 3828-1 |
| | TCP70 | 1/4" x 1" | 1Axxxx | - | HJL<br>HJM | HRK<br>HHB<br>HHI | 3828-1 |

## Tools & resources

- Webpage
- Parametric search tool
- How to select a fuse holder white paper

**Eaton**
**Electronics Division**
1000 Eaton Boulevard
Cleveland, OH 44122
United States
www.eaton.com/electronics

© 2021 Eaton
All Rights Reserved
Printed in USA
Publication No. 10575 BU-MC16086
March 2021

Eaton is a registered trademark.

All other trademarks are property
of their respective owners.

Powering Business Worldwide